




LG2085A - Adhesive Furniture Mount


for LG Models 32LC50C, 32LC5DC & 32LC7DC
with fixed or swivel bases




1. Determine the appropriate location on the furniture for the monitor. Mark the front edge of the monitor's plastic base. Mark a parallel line 3/4" back from the previous line.
2. Clean the furniture surface 2x with an alcohol wipe to remove any residue on the furniture surface.
3. Peel the plastic liner from the Adhesive Squares on the Bottom Plate. Avoid accidental contact between the exposed adhesive and any objects.
4. Align the front edge of the Bottom Plate with the second line marked in step 1.
5. Press the Bottom Plate down putting pressure on each of the six Adhesive Square Locations.
6. Remove the rubber feet from the LG Monitor Base. The Swivel Base has 7 feet and the Fixed Non-Swivel Base has 6 feet.



Fixed Non-Swivel Base (6 Rubber Feet)




Swivel Base (7 Rubber Feet)



Component List


1. Top Plate
1. Bottom Plate
4. Security Screws

Step 7: Fixed Non-Swivel Base



7. Attach the Top Plate to the Monitor Base with the screws removed from the feet.
8. Align the slots on the Top Plate Assembly from step 7 with the rivets on the Bottom Plate. Pull forward on the Top Plate Assembly to lock the two plates together.
9. Attach the LG monitor to the Monitor Base with the provided Security Screws.

Step 7: Swivel Base



Step 9

