

AD Board flash Firmware upgrade instruction.

MODEL: DA00A


Preparation

With power adapter 12VDC, DA00A AD board or monitor, firmware writer tool board, USB cable and D-SUB (VGA) cable. RTD Customer Tool utility is installed in PC or laptop.

Steps:

Step 1

Connect the USB cable from PC or laptop to firmware writer




Step 2

Connect power output cable to AD board by 12VDC adaptor or power on the monitor. Then connect **VGA** cable between tool board and VGA port of AD board or the monitor.




Step 3

Run RTD Tool Customer, select the ISP tab and then select Serial Flash.

**Step 4**


In Serial Flash, click ISP Option to select File Type as Bin and Flash Brand as P-Flash.




Step 5 (Example)

Click BigBin button for open file dialog to select OEM firmware bin code file of


“i-Tech_GTR77_OEM OSD_EDID 1440x9 000x600_AUO_M190PW01_V8(1440x900)_5v8n_20210715”

**Step 6**

When load files successfully, click flash button to write the firmware to AD board.

**Step 7**

The progress bar shows the status of firmware writing and wait till successful.



Step 8

“PASS” will show when writing files to AD board successfully. And then reset parameter in monitor by OSD operation, by select “RECALL” of OSD MENU.

