CMP2000N

Digital Signage
Player Network Guide

iTech Company LLC

phone: (888) 483-2418
email: info@itechlcd.com
web: www.iTechLCD.com

Download and Playback Method from CAT



How to Use AutoPlay Mode in CAT

1. Direct click from playlist editor



2. Select any playlist file by below instructions



AutoPlaylist.mpl is created to be used
Note: must reboot players to run Autoplay



AutoPlay mode can be On/Off on this check box



How to setup
Remote AutoPlay mode
(power up, download and play)

1. Setup FTP/HTTP content folder
• Create URL path on FTP/HTTP server
Ex: FTP://signage.com/../../demo
• Setup user name and password to access
• Use any FTP tool to upload media files

2. Setup "Remote AutoPlay" mode for players
• Use CAT(client setup utility) to setup player's values and http URL sinage.com/../../demo/<name>.mpl
• Click "Update Client" or Save as autoconfig.mia file and copy it to CF card
• Plug CF into player and power up to do auto-updating (all values of autoconfig.mia will be stored into player)



3. Create playlist "<name>.mpl" and upload to FTP URL
• Go to CAT's remote FTP server -> Property
• Enter FTP path, user name and password, then connect
• Browse FTP and select media files to right window
• Click 'Upload Playlist' and enter "<name>.mpl"
• Later, repeat above steps to upload new "<name>.mpl" (Player is required to reboot to download new playlist)

4. Remote AutoPlay Mode
- Power up players
- Payer will automatically download <name>.mpl
- Download contents and playback automatically

Real example to FTP/HTTP Server for Remote Autoplay



Setup remote URL playlist and store into player

Setup FTP for playlist file and Upload





Upload <name>.mpl to FTP

Player and Server Network System Diagram

- CAT is a tool to create playlist file, client setup file
- CAT is a monitoring server to view all clients' activities
- CAT is a real time command server to send IM, RSS to clients

Auto Start Mode: Autoplay thru internet
i-CAT CMS: manage players thru internet
CAT Mode: local LAN direct control





Player Wired and Wireless Connection Diagram