


To change touchpad/trackball module on NK1b

(1) Before your work, please make sure that **the power is disconnected.**

Step 1: Remove the top cover. (5 screws)



Step 2: Disconnect the cable and cut-off the cable tie



Step 3: Remove 7 screws to release the keyboard cover.



Step 4.1: Remove the 6 screws to release the keyboard



Step 4.2: Remove the 4 screws to release the mouse module

